

## Connect Al-1 to computer via USB

Al-1 Quickstart Guide




Connect microphone or instrument using an XLR or 1/4-inch cable (not included)



2

## Enable phantom power (P48) for condenser microphones

Press left knob and P48 light will illuminate red



Disable P48 for dynamic microphones Press left knob again and



Set input level with left knob while checking signal light


Green is good

B



Turn down when Red


Connect headphones (not included) to 1/4-inch output, adjust volume with right knob



Love your Al-1? Share with us **#rodemic** 

@ @rodemic@ rodemic@ @rodemics@ @rodemic






**ON** - Signal goes from mic directly to headphones



OFF - Signal goes from mic through computer to headphones



If using powered speakers, disconnect headphones to activate the balanced speaker outputs

