

# **NT-USB QUICK START GUIDE**

Panduan Memulai Cepat

**RØDE**

1. Letakkan cincin filter pop di sekitar dasar NT-USB Anda.
2. Putar benang pada dasar NT-USB Anda ke dalam pemasangan cincin hingga mikrofon dan filter pop terpasang dengan aman.
3. Pasang tripod yang disertakan ke sisi lain pemasangan cincin dan posisikan sehingga mikrofon dapat duduk dengan stabil di meja Anda.
4. Hubungkan kabel USB yang disertakan ke bagian bawah NT-USB untuk menghubungkannya ke komputer Anda.
5. Pastikan knob atas diatur setengah jalan, dan knob bawah sepenuhnya berlawanan arah jarum jam.
6. Sambungkan headphone ke output 3,5 mm di bawah knob, lalu perlahan-lahan tingkatkan knob bawah hingga Anda dapat dengan nyaman mendengar suara Anda.
7. Sesuaikan knob atas untuk menyeimbangkan volume suara Anda dan audio yang datang dari komputer Anda.

## **NORTH AMERICA**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
  - Increase the separation between the equipment and receiver
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
  - Consult the dealer or an experienced radio/TV technician for help
- CAN ICES-3 (B) / NMB-3 (B)

---

#### **SOUTH KOREA**




ID: R-R-R72-NT-USB  
Company Name: RØDE  
Model: NT-USB  
Country of Origin: Australia


---

#### **POWER**

5V === 100mA

---





To prevent possible hearing damage, do not listen at high volume levels for long periods.





FR

Cet appareil  
se recycle

À DÉPOSER  
EN MAGASIN



OU

À DÉPOSER  
EN DÉCHÈTERIE



Points de collecte sur [www.quefairedemesdechets.fr](http://www.quefairedemesdechets.fr)  
Privilégiez la réparation ou le don de votre appareil !



FR

EMBALLAGES CARTON ET  
GUIDE DE SECURITE A  
RECYCLER



### RØDE Microphones:

107 Carnarvon St, Silverwater NSW 2128, Australia

### Authorised UK Representative:

RØDE UK, Unit A, 23-25 Sunbeam Rd, London  
NW10 6JP, United Kingdom

### Authorised EU Representative:

RØDE EU, Neukirchner Str. 18, 65510 Hünstetten,  
Germany

SCAN FOR MORE INFO



View the user guide to learn more

Lihat panduan pengguna untuk  
mempelajari lebih lanjut



[rode.com](http://rode.com)

0927-0828-02-08